NOTICES

- 1. A slow and steady inhale will produce the best results.
- best results.

 2. Do not overfill or pack your herbs too tightly. This will restrict airflow and produce negative results.

 3. If you're unsatisfied with the amount of vapor being produced, try raising the temperature. If the vapor is too thick, try reducing the temperature.








- 1. Plug the charging adapterinto a wall socket and the other end of the cable into the charging port of the unit.
- 2. LED indicator lights red, meaning in charging. Greenmeans complete.

DEVICE ANATOMY

- Mouthpiece
- Air Intake
- Multi Function Button LED State Indicator
- ◆ LED Temperature Indicator



- 1. Only use a brush (included) tosweep and clean material from chamber.
- 2. Unscrew and clean or replacescreen as needed.
- 3. Do not use cleaning solutions.

- 1. Fully charge the unit.
- 2. Press the mouthpiece from one side to another to expose the heating chamber. It is easy to open from left side to right.
- 3. Grind herbs and place inside heating chamber. Do not overfill or pack too tightly.

1. Power On/Off.

5 clicks in 3 seconds Power on /off the vaporizer.

2. Set Temperature

In heating process, press button beyond 1 second to set temperature. The temperature indicator turns to red at 360F, green at 380F, blue at 420F.

3. Alarm and Protection.

Low Voltage Alarm: LED indicator blinks red for five times, meaning low voltage, then power off.
When heating process last for 10 minutes, the vaporizer will power off automatically.

