

The Anatomy of Your Device

- 1. Cartridge Chamber:**
Magnetically secures your cartridge.
- 2. LED Lights:**
Indicate the activation status on the Series 3.
- 3. Activation button:**
Controls vapour production.
- 4. Metal Charge Port:**
Connects to the Type-C USB charging cord.



Your Vape Pen

The Series 3 can be used with three different e-liquid cartridges: standard e-liquid cartridge with wicks, ceramic e-liquid cartridge and ceramic S3X cartridge with interchangeable coils. Your Series 3 Kit comes with a standard e-liquid cartridge with wicks. Other cartridges can be purchased separately.




S3 E-Liquid




S3 E-Liquid
Ceramic




S3X
E-Liquid

Vsavi™ PRO

SERIES 3

USER MANUAL



www.buyv2cigs.co.uk

YOU MUST BE OF LEGAL SMOKING AGE TO
BUY AND/OR USE ANY VSAVI PRODUCT.

Getting Started With Your Device

1. Remove the Series 3 components from their packaging and charge your device, using the included USB Charger.



2. Unscrew the mouthpiece of your cartridge and fill the chamber with e-liquid.



3. Align the small circle on the side of cartridge (below the mouthpiece) with the notch on your device and slide the cartridge into the cartridge chamber.



4. Unlock your device for use by pressing the activation button five times within two seconds.
5. Press the activation button and discover the satisfaction of Series 3.

Charging Your Device

Series 3 arrives with a partial charge, so make sure you completely charge it before its initiation. Plug the included charger into a USB port and connect the Type-C head to the metal port on the end of the device. The LEDs around the activation button will flash white, indicating that Series 3 is charging. You will see the LED lights intermittently glow white; once the glowing stops and the LED lights go off, it indicates that your Series 3 is fully charged.

The Series 3 will need to be recharged when the red LED lights rapidly flash 10 times. But this will not put your experience on pause – the Series 3 is designed for use while charging. Connect the Series 3 to the USB charger and continue normal use.

Locking and Unlocking The Series 3

Like your mobile phone, the Series 3 has a lock feature to prevent accidental activation. Push the activation button five times within two seconds and you'll see the white LED perimeter flash five times. This will lock the Series 3 and render it unresponsive to accidental actions when not in use. To unlock, push the activation button five times within two seconds. The white LED lights will flash five times, indicating the Series 3 is ready to use.

Cartridge Use

1. Unscrew the mouthpiece from the cartridge and drip e-liquid into the clear chamber.
 - Hold the cartridge at a slight angle when filling it to prevent e-liquid from entering the hollow centre cylinder.
 - Do not fill beyond the fill line.
2. Make sure that the Series 3 is unlocked.
3. Replace the mouthpiece and insert the cartridge into the Series 3 cartridge chamber.
 - Series 3 recognises different e-liquid cartridges. When a standard wick cartridge is installed, the LED perimeter light will flash three times. When a ceramic or 3X cartridge is installed – the LED perimeter light will flash twice.
4. Press the activation button and begin puffing.
 - If the activation button is pressed for 10 seconds or longer while the e-liquid cartridge is in use, the white LED lights will flash five times before the Series 3 automatically cuts off. This eliminates the potential for accidental activation.
5. If you press the activation button and the white LED light flashes three times in quick succession, this means there is no e-liquid cartridge, or there is no connection with the e-liquid cartridge.
Please make sure you have correctly inserted the cartridge and there is nothing between the magnetic connection in the device chamber and the cartridge obstructing the connection.

