

aspire®

# Cobble USER MANUAL

Read this information leaflet fully before you start using this product as it contains important information. The notes below relate to when the device is filled with e-liquid that contains nicotine.

This product is intended for adult smokers. This product is not recommended for non-smokers, young people under the age of 18 years, pregnant or breast feeding women and those experiencing general ill health.



## Contents

- 1\* Cobble device
- 1\* Micro USB Cable
- 1\* Warranty Card
- 1\* User Manual

## Specifications

Cobble AIO Pod capacity: 1.8ml  
Cobble AIO coil integrated into pod, extra pods available  
Built-in Battery Capacity: 700mAh  
Dimensions: 78\*41\*15.5mm  
Automatic draw  
Airflow non-adjustable  
Coil resistance: 1.4Ω  
Coil type: Nichrome  
Easy bottom fill  
Bypass Output



- When using a new pod, let the pod stand for 3 minutes after filling so the cotton can be saturated with e-liquid before use.
- Do not let the pod become completely empty. Refill the pod to avoid dry burning or damage to the coil.

## Cobble AIO Filling

1. Firmly hold the pod, pull the pod away at an angle - from the e-liquid window side. Pod will tilt up and away from the Cobble body.
2. Invert the pod and lift the silicon seal.
3. Place the filling bottle/dropper into the pod filling hole.
4. Squeeze the filling bottle/dropper bulb to add your preferred e-liquid into the pod system.
5. Replace the silicone seal firmly.
6. Re-insert the pod into the power unit, and push down firmly until it 'clicks' into place.



## Instructions

- The Cobble is an auto draw device, just inhale from the drip tip and it will auto fire.
- When the Cobble AIO is in use, the light will indicate your Cobble AIO's current charge. When its current charge capacity is above 3.8 volts the indicator light will be green. When the charge is between 3.5 and 3.8 volts the light will be blue. When the charge drops below 3.5 volts the light will then become red to remind you that it is time to charge your Cobble AIO.

## Protective Features

- Automatic Cutoff: The preset continuous fire time is 8 seconds, after 8 seconds of continuous firing, the LED light will flash green ten times and the Cobble AIO will stop firing.
- Short Circuit Protection: When the Cobble AIO detects a short, it will stop firing, and the LED light will flash green three times.
- Low Voltage Protection: When the battery level drops below 3.3V, the Cobble AIO will not function and the LED light will flash red 15 times to remind you to charge your Cobble AIO.
- Overcharge Protection: When the Cobble AIO is fully charged, it will stop charging to prevent overcharging of your battery.
- Over heat protection: When the temperature of the chip is above 75°C/167°F, the LED light will be green for 3 seconds and the Cobble AIO will cut off.

## Charging Instructions

- Charge via the Micro USB port. Maximum charge current can reach up to 1000mA.
- When the USB cable is attached the Cobble AIO indicator light will flash white three times.
- While charging the LED will indicate the Cobble's current charge status: 3.5 volts or less= red light; 3.5 to 3.8 volts= blue light; 3.8 volts and above =green light. When the Cobble AIO is fully charged the LED will flash white 20 times then remain off.

## IMPORTANT INFORMATION ABOUT USING NICOTINE CONTAINING E-LIQUIDS

Before using nicotine containing e-liquids the user should read the following information carefully.

## NICOTINE CONTAINING E-LIQUIDS:

Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

## WARNINGS AND PRECAUTIONS

**Nicotine containing e-liquids are not recommended for:**

- Non-smokers
- Young people under the age of 18 years;
- Pregnant or breast feeding women; as nicotine is known to cross the placenta and to be excreted in breast milk;
- Those experiencing general ill health; such as heart disease, stomach and duodenal ulcers, liver or kidney problems, long term throat disease or difficulty breathing due to bronchitis, emphysema or asthma;
- Those who have an overactive thyroid gland or have a phaeochromocytoma (a tumour of the adrenal gland that can affect high blood pressure);
- Those who have diabetes, as nicotine may affect your blood sugar levels.
- Those taking the following medication;
- Theophylline (to treat breathing problems)
- Ropinirole (to treat restless legs)
- Clozapine (to treat schizophrenia)



\*Diameter of the pod refill hole.

## POSSIBLE SIDE EFFECTS

If you inhale too much nicotine or use the product too much

you may experience one or more of the following effects:

- Feeling faint;
- Nausea (feeling sick)
- Headache
- Coughing
- Irritation of the mouth or throat
- Dizziness
- Stomach discomfort
- Hiccups
- Nasal congestion
- Vomiting (being sick)
- Heart palpitations
- Abnormal heart rate

If you experience any of these side effects; including any possible side effects not listed in this leaflet, discontinue using the product, if the effect(s) continue after you stop use, consult your doctor or healthcare professional and bring this leaflet to their attention.

To learn more about your products and how to use, please visit: [www.aspirecig.com](http://www.aspirecig.com)

Shenzhen Eigate Technology Co., Ltd.

Building 3, Xinhongtai Industrial Park, 14 Jian'an Rd, Tangwei, Fuyong Town, Bao'an District, Shenzhen, China  
Tel: +86-755-81499783 Email: [service@aspirecig.com](mailto:service@aspirecig.com)

Manufactured By Eigate

MADE IN CHINA

